



Stop Puncture

Repairs and re-inflates tires effortlessly.

Description

Easy to use, the Puncture Stopper allows you to repair and reinflate punctured tyres, from 145 to 245 mm wide, with or without tubes (tubeless), without dismantling or using tools.

Properties

- Repairs and re-inflates tires of a width ranging 145 to 245mm (maximum), with or without inner tube. No tire removal or tools required.
- Can be used on cars, motorcycles or trailers.
- Easy to use. No tire removal necessary.

Instructions for use

- This product may only be used if the tube is not torn and the tire is not off the rim.
- If possible, remove the object that caused the puncture.
- Position the valve at the top.
- Shake well before use.
- Screw the spray tube on the tyre valve.
- Hold the spray in an upright position.
- Remove the security cap and press the button until a sufficient pressure is reached.
- Drive immediately 10-20 km right away at a moderate speed (max 50km/h) to spread the product evenly.
- Check tire pressure and readjust as soon as possible.
- A puncture may have caused damage to the tire.
- Repair should be considered a temporary measure.

Composition

- Active ingredients: Aqueous dispersion of polychloroprene. Preservatives
- Propellant: Butane (Highly flammable)

TotalEnergies Lubrifiants

562, avenue du Parc de l'île
92029 Nanterre Cedex
France

07/2024